



GX470 Relay Bracket Mount Installation Instructions

Tools

12mm Socket
13mm Socket
6" extension / 3" extension
Ratchet

Product ID SMK01201

Document Updated 3/31/2021

Installation Difficulty Easy

Step 1



Start by removing the driver side plastic cover if not already. Remove the bolt shown in **RED** which holds the plastic cover arm (not shown). We will be using the **RED** and **WHITE** holes for mounting

Step 2



Place one M8 bolt and washer as shown into each of the side mount holes

Step 3




Begin fastening both bolts, be sure to not completely tighten one before both are barely snug. There is a slight amount of adjustment to get the bracket level to the engine bay

Step 4



There is a cable that passes through this mounting location, be sure to not pinch it, it will sit freely through the bracket as shown once the bracket is tight

Step 5



There is access to the bottom bolt but we found a 9"-12" extension allows for the easiest access

Step 6



Once installed you are ready to mount the relay box and begin running wires!

Step 7



Final install, happy modding!

Notes:

1) To run the switch panel wire through the firewall the only path we have found is through the main wire boot, this can be very tricky as there is a lot of sensitive wires running through this. It is advised to have a professional aftermarket installer do this. If you are willing to take the risk it is best to use a very sharp knife and delicately make small incisions until you form a small slit. There are 2 layers to the boot on the engine bay side and one layer on the cabin side. Once you have a pass through use a piece of wire to run through the hole, tape the connector to the wire and carefully pull/push the cable through the boot.