



12-21 Impreza/ 13-21 Crosstrek/ 14-18 Forester/ 15-21 WRX/STi Relay Bracket Installation Instructions

Tools

12mm Socket & Ratchet
Phillips Head Screwdriver

Product ID SMK01081 &
 SMK01091

Document Updated 8/15/2021

Installation Difficulty Easy

Step 1



Pull the fuse panel box cover off

Step 2



Remove the bolt for the fuse panel box to the strut tower

Step 3



Remove the forward strut nut

Step 4



Place the bracket on the top hat screw and refasten the nut only slightly, then align the bottom bolt and thread that till snug. Now torque the top nut to 15 ft-lbs, the bottom bolt can be tightened as well (no torque spec). Once complete you are ready to add the relay box!