

Awning Mounts Installation Instructions

Tools

10mm Socket (for M6)	<i>For Gear Mount Only</i>
13mm Socket (for M8)	
7mm Socket	
2.5mm Allen Key	

Product ID SMK01380-SMK01393

Document Updated 9/27/2022

Installation Difficulty Easy

Step 1



Slide the hardware into the existing mount slots, you may need to temporarily remove one of the existing vehicle mounts to slide the hardware to where you desire.



Sizing Information

When sizing what hardware you need to order please measure as shown, the sizes are below.

For M6 Hardware 13/32" or 10mm

For M8 Hardware 1/2" or 13mm

Step 2



Once the hardware is where you want to mount the bracket add the washer then lock nut

Step 3



Tighten down, be sure to go just before snug, get off the vehicle and check the mount is square, once straightened out secure down. Do not over tighten!